

Points to note before powering on the driver:

1. Whether the positive and negative wiring of the power supply is correct (incorrect wiring will burn out the driver)
2. Whether the U V W PE cables are correct (incorrect wiring will cause the driver to burn out or report faults)
3. Whether the wiring of the IN input port is correct (incorrect wiring will burn out the driver)
4. Whether the wiring of the brake is correct. Unsuitable voltage will cause damage to the driver and the brake.